

PARAFLEX LIQUID MEMBRANE SYSTEM CONCRETE (non-nailable)



SLOPE MATERIALS 0" - 2" per foot*
per 100 sq ft

PARAFLEX LIQUID MEMBRANE 3.7 gal
PRO FLEECE
PARAFLEX LIQUID MEMBRANE 1.9 gal

n.t.s.

Requirements and recommendations detailed in the Siplast catalog and Siplast long form specifications shall apply in addition to the following recommendations and specifications.

Application

1. Apply an even, generous base coat of Paraflex Liquid Membrane over the qualified and prepared concrete surface using an approved stub roller at a rate of 3.7 gallons per square.
2. While the previously applied Paraflex Liquid Membrane is still wet, install Pro Fleece reinforcement, embedding the fleece into the liquid material using a roller. Ensure that no air is trapped beneath the fleece. Lap the fleece a minimum of 2 inches side and end, and apply an additional coat of liquid material between layers of overlapping fleece.
3. Immediately following embedment of the Pro Fleece reinforcement, apply an even, generous top coat of Paraflex Liquid Membrane at a rate of 1.9 gallons per square, ensuring full saturation of the fleece.

Ref. #: Pflex-Concrete
Date: 12.29.17