CURB FLASHING (wood curb) PARAFLEX LIQUID MEMBRANE PARAFLEX LIQUID MEMBRANE - CONCRETE SUBSTRATE PARAFLEX LIQUID MEMBRANE REINFORCING FLEECE PARAFLEX LIQUID MEMBRANE COUNTER FLASHING WOOD CURB (Prime wood surfaces to receive Paraflex with Pro Primer W and tape joints with a 2" strip of Eternabond Webseal) PARAFLEX 531 LIQUID FLASHING (fully adhere) STEEL PLATE (fasten to blocking and concrete with appropriate fasteners) MASKING TAPE or DUCT TAPE or ETERNABOND WEBSEAL PARAFLEX LIQUID MEMBRANE (fully adhere) CONCRETE DECK (qualify and prepare concrete surface)

NOTES

1. REFER TO SIPLAST PREPARATION GUIDELINES FOR PROPER SURFACE PREPARATION OF ALL SUBSTRATES PRIOR TO APPLICATION OF PARAFLEX MATERIALS.

2. REQUIREMENTS AND RECOMMENDATIONS DETAILED IN CURRENT SIPLAST SPECIFICATIONS AND THE PARAFLEX LIQUID MEMBRANE SYSTEM INSTALLER'S GUIDE SHALL APPLY IN ADDITION TO THE ABOVE DRAWING.

N.T.S