

PLANTER WITH GEOFOAM INFILL

PARAGREEN INTENSIVE ASSEMBLY - UNINSULATED

CAST IN PLACE CONCRETE
CURB/WALL

REBAR BEYOND

SCUPPER CAST INTO CURB
(size and specifications by others)

PAVER

PEDESTAL SYSTEM

PROTECTION COURSE

VEGETATION

MULCH (by others)

MEMBRANE

PARADRAIN DRAIN MAT
(OPTIONAL)

PARAGREEN INTENSIVE
ENGINEERED GROWING MEDIA

PARAGREEN FILTER FABRIC
(only necessary at transition if drain
mat with filter fabric is installed on
vertical wall)

PARAGREEN DRAINAGE AND
RETENTION MAT

GEOFOAM FILL

PARAGREEN ROOT BARRIER
(see note #2)

SIPLAST MEMBRANE

SUBSTRATE

NOTES:

1. THE VEGETATED ROOF ASSEMBLY IS SHOWN FOR REFERENCE PURPOSES ONLY. DIMENSIONS OF COMPONENTS WILL VARY ACCORDING TO SPECIFIC BUILDING SIZE INSULATION, GROWING MEDIUM AND PERIMETER COMPONENTS.
2. ROOT BARRIER IS OPTIONAL WITH PARAPRO OR PARAFLEX MEMBRANE SYSTEMS.
3. REQUIREMENTS AND RECOMMENDATIONS DETAILED IN CURRENT SIPLAST SPECIFICATIONS SHALL APPLY IN ADDITION TO THE ABOVE DRAWING.
4. DESIGNER OF RECORD TO VERIFY CAPACITY OF DECK/SUBSTRATE TO ACCOMMODATE LOAD OF THE OVERBURDEN COMPONENTS.

CAUTION: SIPLAST RECOMMENDS THAT ALL PRACTICES PERTAINING TO INDUSTRY STANDARD TORCH SAFETY REQUIREMENTS AND GUIDELINES BE FOLLOWED. THIS INCLUDES PERFORMING A FIRE WATCH FOLLOWING ANY TORCH APPLICATIONS. ALWAYS HAVE APPROVED FIRE EXTINGUISHING EQUIPMENT NEARBY WHEN USING A TORCH.

Scale: NTS

REF: PLANTER WITH GEOFOAM INFILL - PARAGREEN INTENSIVE ASSEMBLY - UNINSULATED

Detail Number:
DE-7407M1



14911 Quorum Drive, Suite 600 - Dallas, Texas - 75254 (800) 922-8800

www.siplast.com

Rev: 08.21.2024