## CONCRETE STATIC CRACK PARAPRO ROOF MEMBRANE PARAPRO ROOF MEMBRANE - CONCRETE SUBSTRATE PARAPRO ROOF RESIN REINFORCING FLEECE PARAPRO ROOF RESIN PRO PASTE (chase/prime/fill joint with Pro Paste) PARAPRO ROOF MEMBRANE (fully adhere) CONCRETE DECK (prepare and prime with Pro Primer T)

## NOTES

- 1. REFER TO SIPLAST PREPARATION GUIDELINES FOR PROPER SURFACE TREATMENT OF ALL MATERIALS PRIOR TO APPLICATION OF PARAPRO MATERIALS.
- 2. REQUIREMENTS AND RECOMMENDATIONS DETAILED IN CURRENT SIPLAST SPECIFICATIONS AND THE PARAPRO ROOF SYSTEM INSTALLER'S GUIDE SHALL APPLY IN ADDITION TO THE ABOVE DRAWING.

N.T.S