


CONCRETE OR GYPSUM

nailable



SLOPE 1/2" PER FOOT MIN*

MATERIALS per 100 sq ft

PARABASE FS	20 lb
PA-311 ADHESIVE	1 1/2 - 2 1/2 gal
PARAFOR 50 LT	141 lb

* Contact Siplast for lower slope requirements.

n.t.s.

SPECIFICATION 5000 CBA

Requirements and recommendations detailed in the Siplast catalog and Siplast long form specifications shall apply in addition to the following recommendations and specifications.

APPLICATION

1. Lay one ply of Parabase FS dry over the entire area to be roofed. Lap each sheet 3 inches over the underlying sheet and lap ends 6 inches. Using approved fasteners, nail each sheet every 9 inches through the laps and stagger nail the remainder of the sheet in two rows on nominal 12 inch centers with fasteners in each row on 12 inch centers. *The fastening pattern shown in this specification is based on Siplast standard nailing requirements. Contact Siplast for recommended fastening patterns to meet specific testing or code approvals.*
2. Beginning at the low point of the roof, lay one ply of Parafor 50 LT in a full coating of PA-311 Adhesive, lapping sides a minimum of 4 inches and ends a minimum of 6 inches. Offset end laps a minimum of 3 feet.

Slopes over 2 1/2" per foot: Run all plies parallel to the slope of the roof. The Parafor 50 LT must be back-nailed on slopes over 2 1/2" per foot.

Note: Venting provisions must be incorporated into lightweight insulating concrete designs.



1000 East Rochelle Boulevard Irving, Texas 75062 (800) 922-8800 FAX (469) 995-2206

Ref. #: 0050CBA
Rev. 11.01.06



An Icopal Group Company