


PARAPRO MEMBRANE SYSTEM CONCRETE



SLOPE MATERIAL 0 - 1" per foot*
per 100 sq ft

PRO PRIMER T 3.7 kg
PARAPRO ROOF RESIN 19.0 kg
PRO FLEECE
PARAPRO ROOF RESIN 12.0 kg

SLOPE MATERIALS 0 - 8%*
per sq. meter

PRO PRIMER T 0.4 kg
PARAPRO ROOF RESIN 2.0 kg
PRO FLEECE
PARAPRO ROOF RESIN 1.3 kg

n.t.s.

* Contact Siplast for higher slope requirements.

Specification: PPR-C

Requirements and recommendations detailed in the Siplast catalog and Siplast long form specifications shall apply in addition to the following recommendations and specifications.

Application

1. Where required, apply an even coat of catalyzed Pro Primer T over the prepared concrete surface using an approved roller at a rate of 3.7 kilograms per square.
2. Apply an even, generous base coat of catalyzed Parapro Roof Resin over the primed concrete surface using an approved roller at a rate of 19 kilograms per square.
3. While the previously applied catalyzed Parapro Roof Resin is still wet, install Pro Fleece reinforcement, embedding the fleece into the resin using a roller. Ensure that no air is trapped beneath the fleece. Lap the fleece a minimum 2 inches side and end, and apply an additional coat of catalyzed Parapro Roof Resin between layers of overlapping fleece.
4. Immediately following embedment of the Pro Fleece reinforcement, apply an even, generous top coat of catalyzed Parapro Roof Resin at a rate of 12 kilograms per square, ensuring full saturation of the fleece.

Ref. #: Concrete - Ppro
Rev: 12.18.18