


CONCRETE OR GYPSUM

nailable



SLOPE 0" - 2 1/2" per ft*

MATERIALS per 100 sq ft

PARABASE FS	20 lb
PARADIENE 20 TG	76 lb
PARADIENE 30 FR TG	112 lb

* Contact Siplast for higher slope requirements.

n.t.s.

Specification: 2030 CBT

Requirements and recommendations detailed in the Siplast catalog and Siplast long form specifications shall apply in addition to the following recommendations and specifications.

Application

1. Lay one ply of Parabase FS dry over the entire area to be roofed. Lap each sheet 3 inches over the underlying sheet and lap ends 6 inches. Using approved fasteners, nail each sheet every 9 inches through the laps and stagger nail the remainder of the sheet in two rows on nominal 12 inch centers with fasteners in each row on 12 inch centers. The fastening pattern shown in the specification is based on Siplast standard nailing requirements. Contact Siplast for recommended fastening patterns to meet specific testing or code approvals.
2. Beginning at the low point of the roof, fully torch one ply of Paradiene 20 TG to the Parabase FS surface, lapping sides and ends a minimum of 3 inches. Offset end laps a minimum of 3 feet.
3. Beginning again at the low point of the roof, fully torch one ply of Paradiene 30 FR TG to the Paradiene 20 TG surface, lapping sides and ends a minimum of 3 inches. Offset end laps a minimum of 3 feet. Stagger laps between plies.

Notes: Torch prime all granule surfaces to be lapped by adjoining sheets.

Venting provisions must be incorporated into lightweight insulating concrete designs.

Caution: Siplast recommends that all practices pertaining to NRCA CERTA guidelines be followed when torching methods are employed. This includes performing a fire watch following any torch applications. Always have approved fire-extinguishing equipment nearby.

Ref. #: P20-tg P30-tg LWC-base
Date: 11.2.09



1000 East Rochelle Boulevard Irving, Texas 75062 (800) 922-8800 FAX (469) 995-2206



An Icopal Group Company