DRAIN with INTER-PLY PARAPRO FLASHING **OVERHEAD VIEW** PARADIENE 20/30 FR - RIGID INSULATION PARADIENE 20 (fully adhere) PARAPRO 123 FLASHING SYSTEM (extend a minimum 8" beyond outermost edge of drain) PARADIENE 20 (fully adhere, lap a minimum of 4" beyond Parapro Flashing) MASTIC (set all roof layers above Parapro Flashing in mastic 6" around drain perimeter) PARADIENE 30 FR STRAINER & CLAMPING RING **CLAMPING RING** PARADIENE 30 FR (fully adhere) MASTIC (shaded area) PARADIENE 20 (fully adhere) PARAPRO 123 FLASHING SYSTEM (fully adhere - wipe w/Pro Prep before lapping subsequent sheets)) **PARADIENE 20** (fully adhere to roof surfaces) APPROVED COVERBOARD RIGID INSULATION (slope to drain) NOTES:

- PA-1021 PLASTIC CEMENT, PA-828 FLASHING CEMENT, SFT CEMENT, OR PS-715 NS ELASTOMERIC SEALANT IS REQUIRED WHERE MASTIC IS INDICATED.
- 2. CLEAN/WIPE THE SURFACE OF THE CURED PARAPRO 123 FLASHING WITH PRO PREP AND ALLOW TO DRY PRIOR TO APPLICATION OF THE PARADIENE 20 STRIPPING PLY.
- 3. ROOF DRAIN COMPONENTS AND INSTALLATION GUIDELINES ARE SUPPLIED BY THE DRAIN MANUFACTURER
- 4. REFER TO SIPLAST PREPARATION GUIDELINES FOR PROPER SURFACE TREATMENT OF ALL MATERIALS PRIOR TO APPLICATION OF PARAPRO FLASHING.
- 5. REFER TO SIPLAST FLEECE CUTTING RECOMMENDATIONS FOR CONFIGURATIONS, CUTTING, FOLDING, AND LAPPING TECHNIQUES.
- 6. REQUIREMENTS AND RECOMMENDATIONS DETAILED IN CURRENT SIPLAST SPECIFICATIONS AND THE PARAPRO 123 FLASHING SYSTEM INSTALLER'S GUIDE SHALL APPLY IN ADDITION TO THE ABOVE DRAWING.

CAUTION: SIPLAST RECOMMENDS THAT ALL PRACTICES PERTAINING TO NRCA CERTA GUIDELINES BE FOLLOWED WHEN TORCHING METHODS ARE EMPLOYED. THIS INCLUDES PERFORMING A FIRE WATCH FOLLOWING ANY TORCH APPLICATIONS. ALWAYS HAVE APPROVED FIRE-EXTINGUISHING EQUIPMENT NEARBY.

N.T.S