



NOTES

Refer to WALLcontrol Installer's Guides for detailed instructions regarding the specific products, personal protection, storage, handling, relevant codes, installation tools, substrate preparation, and general application guidelines. Coordinate installation of Siplast WALLcontrol products with the roofing trade to ensure compatibility and continuity with the roofing, waterproofing, and facade systems.

AWB Over Flashing

1. Install **⟨01⟩ Siplast WALLcontrol Stainless Steel Butyl Adhered Flashing** as through wall flashing to the **⟨22⟩ foundation ledge**, adhering at least 2 inches onto **⟨26⟩ drip edge**, and extending a minimum of 8 inches vertically up the wall.
2. Install **⟨25⟩ termination bar** with the fasteners bedded in wet sealant and apply a bead of **⟨06⟩ Siplast PS-715 NS Elastomeric Sealant** along the top edge of the **⟨25⟩ termination bar**. Use a trowel or spatula to tool and seal the joint and the heads of the termination bar fasteners.
3. Install a course of **⟨02⟩ Siplast WALLcontrol Reinforced Aluminum Butyl Adhered AWB** or **⟨04⟩ Siplast WALLcontrol Modified Silicone (STPE) VP Liquid AWB** over the installed **⟨01⟩ Siplast WALLcontrol Stainless Steel Butyl Adhered Flashing** a minimum of 3 inches.

Flashing Over AWB

1. After the AWB is in place, install **⟨01⟩ Siplast WALLcontrol Stainless Steel Butyl Adhered Flashing** as through wall flashing to the **⟨22⟩ foundation ledge**, adhering at least 2 inches onto **⟨26⟩ drip edge**, and extending a minimum of 8 inches vertically up the wall.
Note: If the **⟨01⟩ Siplast WALLcontrol Stainless Steel Butyl Adhered Flashing** is applied over cured **⟨04⟩ Siplast WALLcontrol Modified Silicone (STPE) VP Liquid AWB**, the top edge of the through wall flashing should be wet-set a minimum thickness of 20 mils wet of **⟨04⟩ Siplast WALLcontrol Modified Silicone (STPE) VP Liquid AWB** or **⟨05⟩ Siplast WALLcontrol Modified Silicone (STPE) VP Liquid Flashing** extending the width of the ledge.
2. Install **⟨25⟩ termination bar** with the fasteners bedded in wet sealant and apply a bead of **⟨06⟩ Siplast PS-715 NS Elastomeric Sealant** along the top edge of the **⟨25⟩ termination bar**. Use a trowel or spatula to tool and seal the joint and the heads of the termination bar fasteners.

General Notes:

1. The **⟨21⟩ substrate** must be clean and dry and free from any condition that would be detrimental to the adhesion of the membrane. **⟨08⟩ Siplast Pro Primer AC** is a water-based primer that imparts an aggressive, high-tack finish to improve adhesion to the substrate.
2. Adhered materials must be firmly pressed onto the sheathing using a J-roller.
3. Refer to the relevant manufacturer's install guidelines for proper installation of the **⟨41⟩ cladding** and the **⟨23⟩ insulation**.