


PARAFLEX GREEN ROOF SYSTEM

CONCRETE (non-nailable)



SLOPE	0" to 1" per foot*
MATERIALS	per 100 sq ft
PARAFLEX LIQUID MEMBRANE	3.7 gal
PRO FLEECE	
PARAFLEX LIQUID MEMBRANE	1.9 gal
PARADRAIN EXTENSIVE DRAINAGE MAT	25 lbs
SOIL/PLANTS	

n.t.s.

Requirements and recommendations detailed in the Siplast catalog and Siplast long form specifications shall apply in addition to the following recommendations and specifications.

Application

1. Apply an even, generous base coat of Paraflex Liquid Membrane over the qualified and prepared concrete surface using an approved stub roller at the minimum rate of 3.7 gallons per square.
2. While the previously applied Paraflex Liquid Membrane is still wet, install Pro Fleece reinforcement, embedding the fleece into the liquid material using a roller. Ensure that no air is trapped beneath the fleece. Lap the fleece a minimum 2 inches side and end, and apply an additional coat of liquid material between layers of overlapping fleece.
3. Immediately following embedment of the Pro Fleece reinforcement, apply an even, generous top coat of Paraflex Liquid Membrane at the minimum rate of 1.9 gallons per square, ensuring full saturation of the fleece.
4. Lay one layer of Paradrain Extensive Drainage Mat dry over the Paraflex Liquid Membrane surface.
5. Install soil and plants as specified.

Ref #: Ext-plants-Drain-mat-Pflex-Concrete
Rev: 1.31.18