
CONCRETE OR GYPSUM

nailable



SLOPE 1/4"- 21/2" PER FOOT*

MATERIALS per 100 sq ft

PARABASE FS 20 lb PA-311 ADHESIVE 11/2 - 21/2 gal **PARADIENE 20** 62 lb **PA-311 ADHESIVE** 11/2 gal **PARADIENE 20 PR** 60 lb **PA-311 ADHESIVE** 3 - 5 gal ROOFING GRAVEL 400 lb

Contact Siplast for higher or lower slope requirements.

n.t.s.

SPECIFICATION 2020PR CBA-G

Requirements and recommendations detailed in the Siplast catalog and Siplast long form specifications shall apply in addition to the following recommendations and specifications.

APPLICATION

- 1. Lay one ply of Parabase FS dry over the entire area to be roofed. Lap each sheet 3 inches over the underlying sheet and lap ends 6 inches. Using approved fasteners, nail each sheet every 9 inches through the laps and stagger nail the remainder of the sheet in two rows on nominal 12 inch centers with fasteners in each row on 12 inch centers. The fastening pattern shown in this specification is based on Siplast standard nailing requirements. Contact Siplast for recommended fastening patterns to meet specific testing or code approvals.
- 2. Beginning at the low point of the roof, lay one ply of Paradiene 20 in a full coating of PA-311 Adhesive over the Parabase FS surface, lapping sides and ends a minimum of 3 inches. Offset end laps a minimum of 3 feet.
- 3. Beginning again at the low point of the roof, fully adhere one ply of Paradiene 20 PR to the Paradiene 20 surface using PA-311 Adhesive. Lap sides and ends a minimum of 3 inches. Offset end laps a minimum of 3 feet. Stagger laps between plies.
- 4. Embed the gravel surfacing at a rate of 400 lb/sq in a full coating of PA-311 Adhesive.

Rev 11/02/09

Ref. #: P20-a P20PR-a LWC-base Gravel-a