


PA-750 HOT APPLIED RUBBERIZED ASPHALT PROTECTION COURSE/PEDESTAL/PAVER SYSTEM



SLOPE 0" - 1/2" per ft*

MATERIALS per 100 sq ft

LAYER #1
PA-750 RUBBERIZED ASPHALT 65 lbs
PA-750 FABRIC 15 oz
LAYER #2
PA-750 RUBBERIZED ASPHALT 90 lbs
PROTECTION COURSE
PEDESTAL
PAVER SYSTEM

* Contact Siplast for higher slope requirements.

n.t.s.

Requirements and recommendations detailed in the Siplast catalog and Siplast long form specifications shall apply in addition to the following recommendations and specifications.

Application

1. Prime the entire prepared deck using PA-1125 or PA-917 Primer and allow the primer to dry thoroughly.
2. Apply properly heated PA-750 Rubberized Asphalt with a squeegee to a thickness of 90 mils (0.65 lbs/ft²) over the primed substrate. Ensure PA-750 Rubberized Asphalt is spread evenly and has no air blisters or pinholing.
3. Immediately after the initial PA-750 Rubberized Asphalt application install the PA-750 Reinforcement Fabric, embedding the fabric into the hot asphalt using a squeegee. Ensure that no air is trapped beneath the fabric. Lap the fabric a minimum one inch side and end.
4. Apply the top layer of PA-750 Rubberized Asphalt over the PA-750 Reinforcement Fabric, completely embedding fabric. Ensure the PA-750 Rubberized Asphalt is spread evenly and have no air blisters or pinholing at a thickness of 125 mils (0.90 lbs/ft²).
5. Install the approved protection course over the finished membrane according to the manufacturer's specifications and recommendations.
6. Ballast the system with an approved pedestal paver system according to the paver manufacturer's specifications and recommendations.

Ref. #: Paver-Pedestals-Protect-bd-PA-750-Concrete
Date: 12.07.22



14911 Quorum Drive, Suite 600 - Dallas, TX 75254 (800) 922-8800