


# PARASOLO ROOF MEMBRANE SYSTEMS

## HYBRID SYSTEM



SLOPE	0" - 1" per ft.*
MATERIALS	per 100 sq. ft.
INSULATION	
APPROVED HOT ASPHALT	25lb
PARADIENE 20	62 lb
APPROVED HOT ASPHALT	25lb
PARASOLO PVC FLEECE-BACK	
* Contact Siplast for higher slope requirements.	

n.t.s.

**Specification: SPFANI20H-ALL - All thicknesses - Fleece-Back**

**Requirements and recommendations detailed in the Siplast catalog and Siplast long form specifications shall apply in addition to the following recommendations and specifications.**

### Application

1. Install insulation panels according to manufacturer's recommendations and FM Global requirements, if applicable. The edges of insulation panels should be in moderate contact without forcing and cut to fit neatly against adjoining surfaces. The insulation layer should present a smooth surface to accept the roof membrane.
2. Beginning at the low point of the roof, fully mop one ply of Paradiene 20 to the insulation surface using Approved Hot Asphalt, lapping sides and ends a minimum of 3 inches. Offset end laps a minimum of 3 feet.
3. Fully mop one ply of Parasolo PVC Fleece-Back membrane to the Paradiene 20 surface using approved hot asphalt without wrinkles or buckles, keeping the hot asphalt away from the lap of the adjoining course of Parasolo. Lap Parasolo membrane at sides a minimum of 3 inches. Butt adjacent sheets at end joints.
4. Weld Parasolo Fleece-Back membrane side laps using approved welding equipment and in accordance with heat-welding guidelines.
5. Seam the end joints between adjacent sheets by heat welding an 8 inch wide Parasolo PVC smooth reinforced membrane flashing strip.

Ref. #: Parasolo Fleece-Back - Hot - P20 - Hot - Rigid  
Rev: 01.30.20



1000 Rochelle Boulevard Irving, Texas 75062 (800) 922-8800 FAX (469) 995-2206