


TERAPRO VTS SYSTEM - UNREINFORCED

SUBSTRATE: CONCRETE OVER UNOCCUPIED SPACE



Requirements and recommendations detailed in the Siplast catalog and Terapro VTS Installers Guide shall apply in addition to the following recommendations and specifications.

Preparation & Application

1. Qualify the concrete substrate in accordance with Siplast specifications and prepare by shotblasting or scarification followed by shotblasting to a CSP 4 to CSP 6 profile.
2. Prime the prepared concrete substrate using catalyzed Pro Primer T and allow to cure for a minimum 45 minutes.
3. Apply catalyzed Terapro VTS Resin/Filler mixture evenly over the primed substrate using a trowel or stub roller. Before the mixture is cured, use a spiked roller to smooth the surface.
4. Immediately following use of the spiked roller while the VTS Resin/Filler is still wet, broadcast Terapro VTS Quartz into the VTS Resin/Filler. Allow to cure for 2 hours.
5. Sweep and remove loose/excess quartz. Apply a smooth, even layer of catalyzed Pro Color Finish using a roller.

Ref #: Terapro VTS unreinforced
Rev: 12.18.11