



NOTES

Refer to WALLcontrol Installer's Guides for detailed instructions regarding the specific products, personal protection, storage, handling, relevant codes, installation tools, substrate preparation, and general application guidelines. Coordinate installation of Siplast WALLcontrol products with the roofing trade to ensure compatibility and continuity with the roofing, waterproofing, and facade systems.

Shelf Angle Option

1. Horizontally, at the inside corner of the (39) Floor Structure, apply a bead of (05) Siplast WALLcontrol Modified Silicone (STPE) VP Liquid Flashing or (06) Siplast PS-715 NS Elastomeric Sealant and tool across the corner using a brush or trowel to a minimum thickness of 60 mils wet, extending a minimum of 1 inch onto each substrate on either side of the corner.
2. Install a minimum 6 inches wide piece of (03) Siplast WALLcontrol Reinforced Aluminum Butyl Adhered Flashing (05) Siplast WALLcontrol Modified Silicone (STPE) VP Liquid Flashing, (06) Siplast PS-715 NS Elastomeric Sealant along the joint of the (39) floor structure and (21) substrate.
3. Install (02) Siplast WALLcontrol Reinforced Aluminum Butyl Adhered AWB per Detail 01.S or (04) Siplast WALLcontrol Modified Silicone (STPE) VP Liquid AWB per detail 01.L. When using (02) Siplast WALLcontrol Reinforced Aluminum Butyl Adhered AWB, the course below the (39) floor structure should extend to the underside of the floor a minimum of 3". Use a separate piece of (02) Siplast WALLcontrol Reinforced Aluminum Butyl Adhered AWB under the (39) floor structure and ensure it overlaps the lower course a minimum of 3" and turns up the adjacent wall a minimum of 3".
4. Install the (24) relief angle.
5. Install (26) drip edge for the trough wall flashing and install (01) Siplast WALLcontrol Stainless Steel Butyl Adhered Flashing as through wall flashing. Flashing should extend at least 2 inches onto the edge of the (26) drip edge and a minimum of 2 inches beyond the top of the vertical leg of the (24) relief angle.
6. Install (25) termination bar with the fasteners bedded in wet sealant and apply a bead of (06) Siplast PS-715 NS Elastomeric Sealant along the top edge of the (25) termination bar. Use a trowel or spatula to tool and seal the joint and the heads of the termination bar fasteners.
7. Install a course of (02) Siplast WALLcontrol Reinforced Aluminum Butyl Adhered AWB or (04) Siplast WALLcontrol Modified Silicone (STPE) VP Liquid AWB over the installed (01) Siplast WALLcontrol Stainless Steel Butyl Adhered Flashing a minimum of 3 inches.

Cladding Trim Flashing

1. Horizontally, at the inside corner of the (39) Floor Structure, apply a bead of (05) Siplast WALLcontrol Modified Silicone (STPE) VP Liquid Flashing or (06) Siplast PS-715 NS Elastomeric Sealant and tool across the corner using a brush or trowel to a minimum thickness of 60 mils wet, extending a minimum of 1 inch onto each substrate on either side of the corner.
2. Install a minimum 6 inches wide piece of (03) Siplast WALLcontrol Reinforced Aluminum Butyl Adhered Flashing (05) Siplast WALLcontrol Modified Silicone (STPE) VP Liquid Flashing, (06) Siplast PS-715 NS Elastomeric Sealant along the joint of the (39) floor structure and (21) substrate.
3. Install (02) Siplast WALLcontrol Reinforced Aluminum Butyl Adhered AWB per Detail 01.S or (04) Siplast WALLcontrol Modified Silicone (STPE) VP Liquid AWB per detail 01.L. When using (02) Siplast WALLcontrol Reinforced Aluminum Butyl Adhered AWB, the course below the (39) floor structure should extend to the underside of the floor a minimum of 3". Use a separate piece of (02) Siplast WALLcontrol Reinforced Aluminum Butyl Adhered AWB under the (39) floor structure and ensure it overlaps the lower course a minimum of 3" and turns up the adjacent wall a minimum of 3".
4. Install a course of (02) Siplast WALLcontrol Reinforced Aluminum Butyl Adhered AWB or (04) Siplast WALLcontrol Modified Silicone (STPE) VP Liquid AWB over the installed course extending up from below the (39) floor structure a minimum of 3 inches.
5. Install (32) weep screed with the fasteners bedded in wet sealant.
6. Install a piece of (03) Siplast WALLcontrol Reinforced Aluminum Butyl Adhered Flashing or (05) Siplast WALLcontrol Modified Silicone (STPE) VP Liquid Flashing along the top edge of the (32) weep screed. Flashing should extend at least 2 inches onto the weep screed and a minimum of 2 inches beyond the top edge of the weep screed.
7. When using (03) Siplast WALLcontrol Reinforced Aluminum Butyl Adhered Flashing to seal the top edge of the (32) weep screed, apply ½ inch bead of (05) Siplast WALLcontrol Modified Silicone (STPE) VP Liquid Flashing or (06) Siplast PS-715 NS Elastomeric Sealant or a compatible approved sealant and tool along the top edge of the flashing. Use a trowel or spatula to tool and seal the seam.

General Notes:

1. The (21) substrate must be clean and dry and free from any condition that would be detrimental to the adhesion of the membrane. (08) Siplast Pro Primer AC is a water-based primer that imparts an aggressive, high-tack finish to improve adhesion to the substrate.
2. Adhered materials must be firmly pressed onto the sheathing using a J-roller.
3. Refer to the relevant manufacturer's install guidelines for proper installation of (23) exterior insulation, (42) cladding attachments and (41) cladding.