



AWB Over Weep Screed

Weep Screed Over AWB

NOTES

Refer to WALLcontrol Installer's Guides for detailed instructions regarding the specific products, personal protection, storage, handling, relevant codes, installation tools, substrate preparation, and general application guidelines. Coordinate installation of Siplast WALLcontrol products with the roofing trade to ensure compatibility and continuity with the roofing, waterproofing, and facade systems.

AWB Over Weep Screed

1. Install a minimum 6 inches wide (01) Siplast WALLcontrol Stainless Steel Butyl Adhered Flashing along the joint of the (22) foundation and (21) substrate above grade.
2. Apply a continuous bead of (05) Siplast WALLcontrol Modified Silicone (STPE) VP Liquid Flashing or (06) Siplast PS-715 NS Elastomeric Sealant along the top edge of the (01) Siplast WALLcontrol Stainless Steel Butyl Adhered Flashing and tool the joint. Apply a second continuous bead of (05) Siplast WALLcontrol Modified Silicone (STPE) VP Liquid Flashing or (06) Siplast PS-715 NS Elastomeric Sealant along the center of the (01) Siplast WALLcontrol Stainless Steel Butyl Adhered Flashing, where the (32) weep screed fasteners will be placed.
3. Install (32) weep screed with the fasteners bedded in wet sealant.
4. Install (04) Siplast WALLcontrol Modified Silicone (STPE) VP Liquid AWB or (02) Siplast WALLcontrol Reinforced Aluminum Butyl Adhered AWB. Ensure AWB overlaps the (32) weep screed a minimum of 3 inches for the adhered AWB and 2 inches for the liquid AWB.
5. If the AWB used is (02) Siplast WALLcontrol Reinforced Aluminum Butyl Adhered AWB, apply bead of (05) Siplast WALLcontrol Modified Silicone (STPE) VP Liquid Flashing and tool across the joint using a brush or trowel to a minimum thickness of 60 mils wet, extending a minimum of 2 inches onto the wall and 1 inch onto the (32) weep screed.

Weep Screed Over AWB

1. Install (04) Siplast WALLcontrol Modified Silicone (STPE) VP Liquid AWB or (02) Siplast WALLcontrol Reinforced Aluminum Butyl Adhered AWB to the (21) substrate.
2. Install a minimum 6 inches wide (01) Siplast WALLcontrol Stainless Steel Butyl Adhered Flashing along the joint of the (22) foundation and (21) substrate above grade.

Note: If the (01) Siplast WALLcontrol Stainless Steel Butyl Adhered Flashing is applied over cured (04) Siplast WALLcontrol Modified Silicone (STPE) VP Liquid AWB, the top edge of the through wall flashing should be wet-set a minimum thickness of 20 mils wet of (04) Siplast WALLcontrol Modified Silicone (STPE) VP Liquid AWB or (05) Siplast WALLcontrol Modified Silicone (STPE) VP Liquid Flashing extending the width of the location.

3. Install (32) weep screed with the fasteners bedded in wet sealant.
4. Apply ½ inch bead of (05) Siplast WALLcontrol Modified Silicone (STPE) VP Liquid Flashing or (06) Siplast PS-715 NS Elastomeric Sealant or a compatible approved sealant and tool along the top edge of of the (32) weep screed. Use a trowel or spatula to tool and seal the seam.

General Notes:

1. The (21) substrate must be clean and dry and free from any condition that would be detrimental to the adhesion of the membrane. (08) Siplast Pro Primer AC is a water-based primer that imparts an aggressive, high-tack finish to improve adhesion to the substrate.
2. Adhered materials must be firmly pressed onto the sheathing using a J-roller.
3. Refer to the relevant manufacturer's install guidelines for proper installation of the (37) below-grade waterproofing and the (41) cladding.